

SAR Ceramic Putty

GENERAL DESCRIPTION

SAR is a versatile easy-to-use rebuilding putty with excellent abrasion and chemical resistance. This product is heavily filled with aluminum oxide and can be built up to an inch in thickness or more. Typical applications are for rebuilding of pump casings, slurry tanks, weld seams or anywhere requiring the restoration of metal components.

FEATURES

- Excellent resistance to entrained solids and abrasion
- Very good chemical resistance
- Excellent temperature and thermal shock resistance
- Extended pot life
- May be applied up to thickness of 1 inch or more

PACKAGING

1 kg and 4 kg units

COVERAGE

SAR is a trowel-on rebuilding compound and can be applied up to 1 inch/coat. Thicker applications can be achieved by multiple layers. Theoretical coverage at 125 mils is 1.7 sq. ft. per kg.

MIXING RATIO

2 parts base (B) to 1 part (A) hardener by weight 2 parts base (B) to 1 part (A) hardener by volume

POT LIFE

For a 1 kg unit, mix at 70°F, pot life is approximately 50 minutes. Higher temperatures or larger mass will shorten this time, lower temperatures or smaller mass will extend it. Pot life can also be extended by spreading the mass out to dissipate heat.

COLORS

SAR is grey in color.

TECHNICAL DATA AND INFORMATION

Basic Chemical Resistance at Roor	n Temperature:	
Inorganic Acids	Very Good	
Organic Acids	Good	
Solvents	Good	
Alkalis	Excellent	
Salts	Excellent	
Alcohols	Excellent	
Hydrocarbons	Excellent	
Typical Physical Properties of Cured System:		
Density	1.98	
% Solids	100	
Flexural Strength @ 70°F	20,400 psi	
Tensile Strength @ 70°F	11,900 psi	
Tensile Shear @ 70ºF	3,000 psi	
Max. Dry Operating Temp	425°F	
Operating pH Range	1.5-14.0	

SURFACE PREPARATION

- For maximum adhesion, material should be applied to a firm, clean, dry and abraded surface.
- Best results will be obtained by abrasive blasting the surface.
- If blasting is impractical, a grinding wheel, needle gun, or very stiff wire brush may be used.
- Clean greasy, oily or waxed surfaces with suitable solvent before applying material.

MIXING

Mix <u>ALL</u> of Part A with <u>ALL</u> of Part B. Mixing may be done on a large mixing board or container large enough to hold both the base and hardener. The selected mixing surface <u>must be clean</u> <u>and dry.</u> Mix the material <u>thoroughly</u> until no streaks of any kind are visible. If materials are cold, warm them to 70°F before mixing.

CLEANUP

Most solvents and commonly used thinners such as MEK, acetone, xylene, I,I,I trichloroethane, and safety solvents such as Ensolv, etc., can be used for cleaning tools and equipment. However, as many of these materials are flammable or present other safety hazards, the user should read the MSDS for these materials before using. In no event should these materials be used to clean material from the skin, eyes or clothing.



APPLICATION

SAR is best applied with a squeegee, trowel or the plastic applicator supplied with the kit. Press material thoroughly into substrate and insure a completely wetted out surface. Build up to the required thickness with a second pass. Large cracks or holes should be bridged with glass or metal cloth. Reinforcement should be overcoated.

- Min. Thickness/Coat (mils)
 40
- Max. Thickness/Coat (mils) 1000
- Number of Coats
- Min. Application Temperature (°F) 50

For best results, do not apply:

- When humidity is over 90%
- When there is moisture on the surface
- When surface temperature is not 5°F above dew point

1

OVERCOATING

For pinhole control and/or thicker buildup, two or more coats may be employed. **SAR** may be overcoated with other **DUROMAR** materials such as **EAC** or **EXP** for enhanced smoothness or increased chemical resistance. Overcoating may begin as soon as the first coat is firm enough to accept a second coat. In high humidity or cold temperatures a blush may develop which should first be wiped down with clean water. The following table is an approximate guide to the earliest and latest times an overcoat may be applied:

SAR Overcoating Window:

55°F	70°F	85ºF
4-12 h	2-6 h	1-3 h

At 70°F, if 6 hours have elapsed or the material is dry to the touch, it must be roughened before overcoating. The preferred method is a light abrasive brush blasting. Other treatments are light sanding, grinding or wire brushing.

CURING @ 70°F

- Dry to Touch (hours) 4Functional Cure (hours) 24
- Full Cure (hours) 120

Q/C

The material should be visually inspected just after application and touched up where necessary. The material may also be spark tested once a full cure has been attained. A general rule is to spark test at a voltage of 100 volts per mil of thickness. Any imperfections should be handled according to the overcoating procedures outlined above.

FORCE CURING

Force cures are recommended for severe service conditions as both the physical and chemical properties are enhanced. Force curing should not start until material has firmly set.

Recommended Force Cure Schedule:

- Full Cure 4 hours @ 180°F
- Functional Cure 8 hours @ 120°F

STORAGE/SHELF LIFE

Store in dry area in closed containers between 50°F and 100°F. Shelf life at these conditions is greater than one year.

HEALTH AND SAFETY

READ AND UNDERSTAND ALL MATERIAL GIVEN IN THE MSDS SHEETS BEFORE USING THE PRODUCT.

SAR DOES NOT CONTAIN ANY FLAMMABLE MATERIAL OF ANY KIND. HOWEVER, THE MATERIAL IS COMBUSTIBLE. IN THE EVENT OF A FIRE, DRY POWDER, FOAM, OR CARBON DIOXIDE FIRE EXTINGUISHERS SHOULD BE USED. FIRE FIGHTERS SHOULD WEAR RESPIRATORS.

USE PROTECTIVE GLOVES AND EYEGLASSES WHEN USING.

USE IN AREAS OF GOOD VENTILATION.

LIMITED WARRANTY

All recommendations covering the use of this product are based on past experience and laboratory findings. Methods or conditions of application and use of the product are beyond our control. We assume responsibility only for the uniformity of our product within normal manufacturing balances.

All Duromar products are formulated based on over 25 years of experience, laboratory tests, material data, field installations, and technical publications, which we believe to be, to the best of our knowledge, accurate and reliable. This information is intended to be used for guidance only. Because the only true reliable test is one that is in actual operation, Duromar will make available at no charge samples of materials for that testing purpose. Duromar, Inc. has no control over either the quality or condition of the substrate, or the many factors affecting the use and application of the product. Duromar, Inc. does, therefore, not accept any liability arising from loss, injury, or damage resulting from such use or the contents of this data sheet (unless there are written agreements stating otherwise). The data contained herein is liable to modification as a result of practical experience and continuous product development. This data sheet replaces and annuls all previous issues, and it is, therefore, the user's responsibility to ensure that this sheet is current prior to using the product.

Rev. 05/13

